
# U-B30/B30Y





# USER'S MANUAL

# **Contents**

Packing, Transport and storage

**Manual Introduction** 

Chapter1. Description of the machine

**Chapter 2. Specifications** 

Chapter 3. Safety

**Chapter4.** Installation

Chapter 5. Adjustment

Chapter6. Maintenance and care

Chapter 7. Failure and resolutions

**Chapter8. Accessory** 

PACKING, TRANSPORT AND STORAGE



ALL PACKING, LIFTING, HANDLING, TRANSPORT AND UNPACKING OPERATIONS ARE TO BE PERFORMED EXCLUSIVELY BY EXPERT PERSONNEL


# PACKING (Picture1)

### Standard equipment

	main beam and sub beam (1 # CTN), control box 2# CTN), oil line and accessory and				
	bridge plate and back Pipe line shield (3# CTN), total is3 pieces.				
Packi	ng List				
Tacki					
CTN	Name	Accessory name and quantity			
NO					
1.	lift beam	main beam one piece& sub beam one piece			
2.	control box				
		M16 ground bolt 12 sets; M8 ground bolt 24 sets.			
		$\phi$ 6×4mm air pipe 1 set(including one three-way air pipe); $\phi$ 8×5mm air pipe 2 sets;			
		tie-strip 10 pieces;			
		high pressure pipe 6 pieces;			
		Thin rubber cushion and thick rubber cushion 4 each one maintenance and use manual:			

sealing ring (two  $\phi 8$  combined cushions);

3. Pipe line and one  $\phi 6$  three-way air pipe connection;



250MM directly knee one unit.

B30Y: 750MM four units, 490MM two units, 250MM directly knee one unit.

Table 1

Packing dimension picture

U-B30(B30Y) Picture 1

### PACKING, TRANSPORT AND STORAGE


Transport (Picture 2)

Packing can be lifted or moved by lift trucks, cranes or bridge cranes. In case of slinging, a second person must always take care of the load, in order to avoid dangerous oscillations.

During loading and unloading operation, goods must be handled by vehicles or ships. At the arrival of the goods, verify that all items specified in the delivery notes are included. in case of missing parts, possible defects or damage due to transport operations.

If finding missing parts, possible defects or damage due to transport, one should examine damaged cartons according to << Packing List.>> to verify the condition of damaged goods and missing parts, also the person in charge or the carrier must be immediately informed.

The machine is heavy goods! Don't take manpower load and unload and transporting way



# Goods-lifted picture

# Storage:

- -The machine equipment should be stocked in the warehouse, if stocked outside should do the disposal well of waterproof.
- -Use box truck in the process of transport, use container storage when shipping.
- -The control box should be placed perpendicularly during the transport; and prevent other goods from extrusion.
- -The temperature for machine storage :  $-25^{\circ}$  C  $--55^{\circ}$   $^{\circ}$  C

#### Manual Introduction



This manual has been prepared for workshop personnel expert in the use of the lift operator and technicians responsible for routine maintenance fitter.

Workers should read the << Maintenance & Use Manual>> carefully before carrying out any operation with the lift. This manual contains important information regarding:

-The personal safety of operators and maintenance workers.



- -Lift safety,
- -The safety of lifted vehicles

#### CONSERVING THE MANUAL

This manual is an integral part of the lift.

The manual must be kept in the vicinity of the lift, so that the operator and maintenance staff must be able to locate and consult the manual quickly and at any time.



Attentively reading Chapter 3, which contains important information and safety warning, is particularly recommended.

The lift is designed and manufactured according to European Standard

The lifting, transport, unpacking, assembly, installation, starting up, initial adjustment and testing, extraordinary maintenance, repair, overhauls, transport and dismantling of the lift must be performed by specialized personnel from the licensed dealer authorized by the manufacturer.



The manufacturer declines all responsibility for injury to persons or damage to vehicles or objects when any of the above mentioned operations has been performed by unauthorized personnel or when the rack has been subject to improper use.

This manual indicates: the operative and safety aspects that may prove useful to the operator and maintenance worker. For better understanding the structure and operation of the lift and for best use of the same, workers must read the <<Maintenance & Use Manual>> carefully before carrying out it.



In order to understand the terminology used in this manual, the maintenance and repair activities, the ability to interpret correctly the drawings and descriptions contained in the manual and be the country in which the machine has been installed. The same applies to the maintenance and the maintenance fitter must also possess specific and specialized knowledge both in mechanical and engineering field.

OPERATOR: person authorized to use the lift

MAINTENANCE FITTER: person authorized for routine maintenance of the lift.

Manufacturer owns the right to make little change for the manual owing to the improvement of technology.

# Chapter1. Description of the machine

# Machine Application:

small platform profile scissor lift can lift each kind of vehicle whose weight is less than 3000kg, suitable for use in vehicle tests, maintenance, wheel alignment and caring for automobiles, which is particularly suitable for use in the basement or on the floor, without construction and hole.

#### **Structure Features:**

- -use hidden and thin scissor structure, dispense with construction and ground hole, the occupation is small
- -independent control box, low-voltage controlling, good security
- -same hydraulic cubage and in-phase cylinder, the synchronization of platform
- -own the double safety equipment of hydraulic lock and mechanical pawl, on the safe side
- -own protection of safety valve and burst-proof equipment for hydraulic failure and over loading. So when the oil pipe bursts, the machine will not fall quickly.
- -use high quality hydraulic or electric element parts made in Italy, Germany, Japan and so on.
- -own manual lowering operation when the power is cut.

### Equipment:

- -machine basement (The position and space of equipment installation)
- -machine frame (The main structure of lift and insurance institution)
- -control box (Machine-controlled part)

#### Basic structure

The machine basement is made of cement and concrete



Make of steel connecting rod, main lifting platform, sliding board, pneumatic double tooth, hydraulic oil tank.

Under the control box is hydraulic oil tank and hydraulic pump, valve and other control system. On the control box is electrical system.

Scissor lift is designed and built to lift all kinds of vehicles, all other use are unauthorized. In particular, the lift is not suitable for washing spray work. And not lift the vehicle whose weight exceeds the maximum weight.

Chapter 2.SPECIFICATIONS

	Chapter 2:51 Een Tern Torn			
	Main technical parameter			
Machine type	U-B30	U-B30Y		
Drive	Electrical hydraulic	Electrical hydraulic		
Max lift weight	3000kg	3000kg		
Main machine lift height	1850mm	1850mm		
Platform initial height	110mm	110mm		
Platform length	1450mm	1450-2050 mm		
Platform width	635mm	635mm		
Lifting time	≤50s	€50s		
descent time	≤60s	≤60s		
Whole machine length	2040mm	2040mm		
Whole machine width	2020 mm	2020 mm		
Whole machine weight	850kg	850kg		
Power supply	AC 400V 或 230V±5% 50Hz	AC 400V 或 230V±5% 50Hz		
Whole machine power	2.2KW	2.2KW		
Hydraulic oil	12L corresponds to wearable hydraulic oil	12L corresponds to wearable hydraulic oil		

air pressure 6-8kg/cm<sub>2</sub> 6-8kg/cm<sub>2</sub> 5-40°C 5-40°C Working temperature 1450-2050 Working humidity 30-95% 30-95% Noisy < 76db < 76db height above sea level≤1000M height above sea level≤1000M Installation height Storage temperature -25°C~55°C -25℃~55℃ Table 2 Lift dimension picture: 2040

U-B30Y

7

Picture 3

# Chapter 2.SPECIFICATIONS


Motor	pump
Type	Type P4.3  Model gear pump  Max flux 4.3cc/r  Joint type joint overfull valve
Max Frequency 50Hz Poles 4 Speed 1450rpm/min Building shape B14 Insulation class F When connecting the motor refer to the enclosed diagrams, and the motor	Continuous working pressure······210barIntermittent pressure····150~300barInject 20 litters of wearable hydraulic oil into the oil tank.
direction is alcologies	

direction is clockwise

# INSTALLATION SCHEME FOR SCISSOR LIFT

# Requirements:

concrete type 425#, the period of desiccation is 15 days



# **Equipment basic picture Picture 4 (The control box can be placed on the left or right )**




# Chapter 2.SPECIFICATIONS

Note: The foundation of the end of the lift platformP1, P2 is the structure of concrete. When the thickness of inside level ground is less than 150mm, the end of P1, P2 should be irrigated the acreage: 2500×2500mm and thickness of concrete ≥150mm The basic thickness of concrete and leveling are keys, shouldn't egregiously expect the ability of level adjustment of machine-self.

### TYPES OF VECHLES SUITABLE FOR:

This lift are suitable for virtually all vehicles with total weight and with dimensions not exceeding the below data.

# MAXIMUM WEIGHT





Min.(mm) M	[ax.(	(mm)
------------	-------	------

A	2000	4000

D 900

# Picture 5

THE LOWER PARTS OF THE VECHILE UNDERBODY COULD INTERFERE WITH STRUCTURAL PARTS OF THE LIFT, TAKE PARTICULAR PARTS OF THE SPORTS-CAR.

The lift will also handle customized or non-standard vehicles provided they are within the maximum specified carrying capacity.

Also the personnel safety zone must be defined in relation to vehicle with unusual dimensions.



Read this chapter carefully and completely since important information for the safety of the operator or others in case of improper use of the lift is included.

In the following text there are clear explanations regarding certain situations of risk or danger that may arise during the operation or maintenance of the lift, the safety device installed and the correct use of such systems, residual risks and operative procedures to use (general specific precautions to eliminate potential hazards).



Lifts are designed and built to lift vehicles and hold them in the elevated position in an enclosed workshop. All other uses of the lifts are unauthorized. In particular, the lifts are not suitable for:

- -washing spray work;
- -creating raised platforms for personnel or lifting personnel;



- -use as a press for crushing purposes;
- -use as elevator;
- -use as a lift jack for lifting vehicle bodies or changing wheels.

The manufacturer is not liable for any injury to persons or damage to vehicles and other property caused by the incorrect and unauthorized use of the lifts.

During lifting and descent, the operator must remain in the control station as the diagrams illustrated.



As the diagrams illustrated: The presence of persons inside the danger zone indicated is strictly prohibited. During operations persons are admitted to the area beneath the vehicle only when the vehicle is already in the elevated position, when the platforms are stationary, and when the mechanical safety devices are firmly engaged (eg: the safety gear is completely locked).

DO NOT USE THE LIFT WITHOUT PROPECION DEVICES OR WITH THE PROTECTION DEVICES INHIBITED.

FAILURE TO COMPLY WITH THESE REQUEATION CAN CAUSE SERIOUS INJURY TO PERSONS, AND IRREPEARABLE DAMAGE TO THE LIFT AND THE VEHICLE BEIN LIFED.

# Picture 6

10



#### GENERAL PRECAUTIONS

The operator and the maintenance fitter are required to observe the prescriptions of safety regulation in force in the country of installation of the lift.

Furthermore, the operator and maintenance fitter must:

-always work in the stations specified and illustrated in this manual;



-never remove or deactivate the guards and mechanical, electrical, or other types of safety devices;



-read the safety notices placed on the machine and the safety information in this manual.

In the manual all safety notices are shown as follows:

WARNING: indicates following operations that are unsafe and can cause minor injury to persons and damage the lift, the vehicle or other property.

CAUTION: indicates possible danger that can result in serious injury to people and damage property.

OF ELECTRIC SHOCK: a specific safety notice placed on the lift in areas the risk of electric shock is particularly high.

#### RISK AND PROTECTION DEVICES

We shall now examine the risks that operators or maintenance fitters may be exposed to when the vehicle is standing on the platforms in the raised position, together with the various safety and protection devices adopted by the manufacturer to reduce all such hazards to the minimum:

For optimal personal safety and safety of vehicles, observe the following regulations:

-do not enter the safety and safety of vehicles are being lifted. (Picture 6)

-make sure the vehicle is positioned correctly (Picture 7)

-be sure to lift only approved vehicles, never exceed the specified carrying capacity, maximum height, are specified (vehicle length and with):

-make sure that their person on the platform the g up and down movements and during standing.





Picture 7

Picture 8 Picture 9

11


#### GENERAL RISKS FOR LIFTING OR DESCENT:

The following safety equipments is used to protect over loading or the possibility of engine failure.

In the condition of over loading, the overflow valve will open and directly return oil to the oil tank. (see Picture 8)

Each bottom of oil cylinder is equipped with antiknock and locked valve. When the oil pipe is burst in the circuit of hydraulic pressure, the relevant antiknock and locked see Picture 9) valve will wo

Safety tooth and beneath the machine in fall integrity of ger 10)







Picture 10 Safety tooth and gear module

ule and that t



There is nothing abnormal should be left on the safety modules to prevent safety gear from occlude normally.

#### RISKS FOR PERSONNEL



This heading illustrates potential risks for the operator, maintenance fitter, or any other person present in the area around the lift, result from incorrect use of the lift.

#### RISKS FOR EXTRUSION

During up and down operations, personnel leave the said area without following the rule and instruction.

During up and down operations, no person is admitted to work beneath the movable parts of the lift, should work in the safe zone. (Picture 6)

#### RISK OF IMPACT

Before the operator begin up and down movements, make sure that there are no personnel inside the danger zone. When, due to operational reasons, the lift is stopped at relatively low elevation (lower than 1.75m above the ground) personnel must be careful to avoid impact with parts of the machine not marked with special colors.

1111111111111111



# RISK OF FALLING OFF (PERSONNEL)

During up and down operations, personnel are prohibited from entering the platforms and the vehicle to avoid falling off.



# RISK OF FALLING (VEHICLE)

This hazard may arise in the case of incorrect positioning of the vehicle on the platforms, overweight of the vehicle, or in the case of vehicles of dimensions that are not compatible with the capacity of the lift.



The photocell does not work well to let the lift platforms do not in the same level.



When the platform is being tested, the vehicle engine can not be turned on.

There is nothing should be placed on the lift-lowering area and the movable parts of the lift.

#### RISK OF SLIPPINE

Caused by lubricant contamination of the floor around the lift. The area beneath and immediately surrounding the lift and also the platforms must be kept clean. Remove any oil spills immediately.





#### Picture 12



#### RISK OF ELECTRIC SHOCK

Risk of electric shock in areas of insulated and shattered electric equipments.

Do not use jets of water, steam solvents or paint next to the lift, and take special care to keep such substances clear of the electrical control panel.



#### RISKS RELATED TO IMAPPROPRIATE LIGHTING

The operator and the maintenance fitter must be able to assure that all the areas of the lift are properly and uniformly illuminate compliance with the laws in force in the place of installation.

During up and down operations, the operator should continually observe the lift and can operate it only in the position of operator. When lifting and lowering the vehicle, the cushion needs being put in the bottom of chassis.

The handling of safety devices is strictly forbidden. Never exceed the maximum carrying capacity of the lift, make sure the vehicles to be lifted have no load.


It is therefore essential to adhere scrupulously to all regulations regarding use, maintenance and safety contained in this manual.

# Chapter 4.INSTALLATION



SKILLED AND AUTHORIZED PERSONNEL ONLY SHOULD BE ALLOWED TO PERFORM THESE OPERATIONS, FOLLOW ALL INSTRUCTIONS SHOWN BELOW CAREFULLY, IN ORDER TO PREVENT POSSIBLE DAMAGE TO THE CAR LIFT OR RISK OF INJURY TO PEOPLE.

Skilled technicians only, appointed by the same manufacturer or by authorized dealers, are allowed to install the car lift.



#### Picture 13

- The car lift must be installed according to the specified safety distances from walls, pole and what other equipments stated.
- The specified safety distances from walls must be 600 mm at least, taking into consideration the necessary space to work easily. Because space for the control site and for possible runways in case of emergency is also necessary.
- The room must be previously arranged for the power supply and pneumatic feed of the car lift.
- The room must be 4000 mm in height, at least.
- The car lift can be placed on any floor, as long as it is perfectly level and sufficiently resistant. (≥250kg/cm², the thickness of concrete ≥150mm)
- · All parts of the machine must be uniformly lit with sufficient light to make sure that the adjustment and maintenance operations can be performed safely, and without reflected light, glare that could give rise to eye fatigue.
- The integrality of arrived goods should be checked before the lift is installed.
- · Moving and installing lift should follow the process as the picture instructs.

The transport and storage of machine refers to "TRANSPORT AND STORAGE" on page

# Picture 14

# Platform Installation:

- -Place two lift platforms on the position of the location
- -The bottom of oil cylinder is located in the frontage of machine (the direction of getting on the vehicle)

# Chapter 4.INSTALLATION

-Use fork car or other lifting equipments to lift the platform (Picture 14) and make sure that the safety equipment of machine is both turned on and locked.



To avoid failure of machine safety equipment, can insert a wood in the middle part of joint-pole.

Prohibit working beneath the lift when hydraulic system is not completely equipped with hydraulic oil and take the action of up and down operations.

-When moving the lift platform, adjust the space between two platforms, make sure that the two platforms are parallel.

#### LINE CONNECTION



Connect the electrical and oil line according to <<th>electric wiring diagram>> and <<oil line connection>>.

Only after connecting the hydraulic system can connect the air loop, can not damage oil pipe, wire, and air pipe.

In the process of connecting oil pipe and air pipe, pay particularly attention to the protection of pipe tie-in to prevent abnormal thing from entering oil loop and air loop, then damaging hydraulic system.

#### ELECRIC CIRCUIT CONNECTION:

Follow the stated line-diameter and line-number of <<the electric wiring diagram>> to connect electric circuit.



3 PE L1 L2 L3

Picture 15 Picture 16

Only skilled special person is allowed to perform the operations.

- open the control box' front cover



-connection of power supply: the 400VAC three-phase and four-line connection wires (4×2.5mm<sub>2</sub> cable wire) for power supply are connected to L1,L2,L3, and PE labeled entering-wire terminal in control box. The PE ground wire is connected under the bolt marked ground firstly (Picture 15) and then connected under the bolt marked ground of two platforms.

-if the lift is operated at 230V single-phase, change the connection on the transformer and motor. (Picture 16)

#### HYDRAULIC PIPELINE CONNECTION:

Follow <<oil line diagram >> to connect the hydraulic oil pipes.

Only skilled and authorized person is allowed to perform the operations. And pay particularly attention to the protection of vita head.

- -Following tubing number to lead the high-pressure tubing out from the "working stop valve G" and two "oil make-up stop valve H, I" of control box and then connect it to oil cylinder. (Refer to <<oil line diagram>>)
- -when connecting tubing, pay attention to the protection of tubing tie-in to prevent impurities from entering hydraulic circuit.

When connecting the tubing, be care of the mistake of each tubing number.

During the standard installation, control box is in the nearside of vehicle-entering direction. If placed on the right should adjust relevant tubing.

# Chapter 4. INSTALLATION

# COMPRESSED AIR PIPE CONNEVTION:



Follow <<air loop diagram >> to connect air loop.

Only skilled and authorized person is allowed to perform the operations.

- -Connect  $\Phi$  8  $\times$  6 compressed air supply pipe to the air supply jaws of pneumatic electromagnetic valve inside the control box. (Picture 17)
- -Follow <<air loop diagram >> to lead the compressed air pipe out from pneumatic electromagnetic valve and then connect it to the uplifted-pawl air valve. (Picture 18)

-Pay attention to the protection of windpipe tie in to prevent impurities from entering compressed air circuit.

-Connect compressed air pipe to the extra-installed greats separator which is in front of control box to prolong the life of pneumatic components and the reliability of action.



Picture 17 Picture 18

In the process of windpipe installation, the windpipe can not be folded or tied to avoid that the air loop is not smooth or it is jammed.

Before leading the compressed air supply pipe to the air supply jaws of pneumatic electromagnetic valve inside the control box, should extra install grease separator to separate compressed air, avoiding the failure of pneumatic cell action.



Chapter 5.Adjustment

Add oil and check the order of phase.

After installing lift as Picture 4 required and connecting hydraulic circuit, electric circuit and air loop, operate it as following:




-open the hydraulic oil tank, add 18L of hydraulic oil into the oil tank, the hydraulic oil is provided by the user.

Make sure the clean of hydraulic oil, prevent any impurity into the oil line, lead the digest of the oil line and no working of the sole poid valve.

-push on the power, press the "up" button, check whether the motor turns clockwise (looking downward), if not, push off the power, exchange two enter line wires.

-turn on air power



#### Picture 19

When turn on power, the high voltage will exist in the control box, only authorized person can operate it.

#### Oil make-up adjustment

- 1. Open all 3 ball stop valve (Rotate the valve G 1~2 times in a counter clockwise direction, make handle of the valve H and I parallel to valve's body).
- 2. Press "UP" button SB1, motor start to lift the two platforms to the apex.
- 3. Close the valve G (Rotate the valve G  $1\sim2$  times in a clockwise direction).
- 4. Vent air by Loosen the screws at the top of main oil cyclinders, then press "UP" button SB1. Tighten the screws after there is no air vent out from the oil cyclinder.
- 5. Open the valve G(Rotate the valve G 1~2 times in a clockwise direction) and close the valve H and I(make handle of the valve H and I perpendicular to the body of valve). Press "DOWN" button SB2 to let the two platforms down to the ground.



- 6. Repeat the step 2 to step 5 for 4-5 times until there is no air out.
- 7. Finish the oil make-up and air bleeding process.

#### Platforms level micro adjustment

- A. Press the "UP" button SB1 to lift the two platforms to going up to about 100 mm.
- B. Close the valve G, and open the valve H OR I.
- C. Inching "UP" button and "DOWN" button to adjust the platform to going up and down to let them at the same level. Then close the valve I OR the valve H. Open the valve G.


Check: whether the locations of two safety-pawl equipments are agile and reliable, no leakage of the hydraulic system and the air system.


# GROUND BOLTS INSTALLATION:

The ground bolts installation must start after the expiry date on the maintenance of concert, otherwise, it will affect the quality of solidity.

- -adjust the parallel of the platform and the distance of two platform as Picture 4 requires.
- fix the anchor bolts with a percussion electric drill (percussion drill bit is of 16), drill to 120mm hole and clean the hole.
- -use light hammer to install the ground holts into the hole ( need not install the central expanded nail of ground bolts, install it after level adjustment.)

USER'S MANUAL
Chapter 5 Adjustment





- By using a level bar and the horizontal pipe and adjusting the adjustment screws at tow sides of the base plate.
- -If platform unevenness is resulted from basic unevenness, use iron block to fill up the low place.
- -After level adjustment, insert the central expanded nail of ground bolts and use heavy hammer to hammer it.
- -Screw down the ground bolts cap





#### Picture 21

When the expiry date on the maintenance of concrete hasn't arrived, can not install the central expanded nail of ground bolts.

the gap between the base plate and ground after adjustment must be filled with iron plate or concrete.

No load of main machine test:

-turn on the power QS.

- -press "up" button SB1, pay attention to the synchronization and placidity of the lifting.
- -check whether safety pawl is correctly located.
- -check whether the oil line and the air line are leakage.

When testing the lift, no person or other things are allowed to stand or be put near the two sides and beneath the machine. If any abnormal is found, press button "SB0" to stop it timely. After clearing obstacles, do the test again.

### Load of machine test:

- -Drive the vehicle whose weight doesn't exceed maximum lift weight to the platform, and then the driver leave it.
- -Put the lift rubber cushion on the strut-seat.
- -press "up" button SB1, lift the platform and pay attention to the synchronization and placidity of the lifting.
- -check whether safety pawl is correctly located.
- -check whether the oil line and the air line are leakage.

### Chapter 5.Adjustment



When beginning load of machine test, no person or other things are allowed to stand or be put near the two sides and beneath the machine.

Test vehicle whose weight doesn't exceed maximum lift weight.




Check whether the oil line and the air line are leakage. If any abnormal is found, press button "SB0" to stop it timely. After clearing obstacles, do the test again.

Only skilled and having been trained personnel is allowed to perform the operations. Check proceedings as following.

### **Operation Notices:**

- -clear obstacles around the lift before operation.
- -during lifting or lowering, no person is allowed to stand neat the two sides and beneath the machine, and no person is allowed on the two platform.
- -avoid lifting super heavy vehicles or other goods.
- -when lifting vehicle, the chassis of the vehicle should be filled up with rubber cushion.
- -pay attention to the synchroscapsofthe **Lift**ing and lowering. If any abnormal is found, stop the machine timely, check and remove the trouble.
- -when lowering vehicle, lift the platform a bit firstly, notice that whether two safety pawls and safety teeth have been disengaged completely. If not, stop lowering.
- -when the equipment is not used for a long time or over night, the machine should be lowered to the lowest position on ground, and remove vehicle, and cut off power supply.

Instructions on electric operation: (see the operation panel)



## LIFTING:

-press "lift" button SB1, the oil pump will work immediately, hydraulic oil is sent to hydraulic cylinder through "the work stop valve", the platform is being lifted and the safety pawl is also lifted because of air loop.

-release button SB1, the oil pump will stop immediately, the platform stops lifting and the safety pawl falls on the safety gear because electromagnetic air-valve is out of electricity and then close the air loop.

## **DESCENT:**

-press "DOWN" button SB2, the safety pawl will be lifted by joint air loop, the electromagnetic valve opens because of electricity. The platform is lifting for  $2{\sim}3s$  first and then lowing, release button SB2, stop lowering, the safety pawl falls on the safety gear.

## Emergency stop

When the machine has abnormal or car maintenance, push "emergency stop" button "SB0" and locking, cut off all the operation circuit, other operation can not be work.



Chapter 5.Adjustment

Oil make-up "adjust" operation (normal service period):



after completion of machine installation and adjustment in the application process, the right platform is lower than the left one because of air in the oil cylinder not being excluded completely normal looses or leakage of the hydraulic oil.

When conducting oil make-up operation, the platforms must not be load.

### Adjustment process:

- -switch off "the work stop valve G" (dextrorotary)
- -If the left platform is little lower (P1), turn on "the oil make-up valve H" (clockwise rotation  $90^{\circ}$ )



- -If the right platform is little lower (P2), turn on "the oil make-up valve I" (clockwise rotation 90°)
- -Click the "lift" button SB1, and then the single side of platform is lifted alone.
- -after the two platforms both have the same height, close the oil make-up stop valve "H" or "I", turn on "the work stop valve", the oil adjustment process comes to the end.

# EMERGENCY MANUAL OPERATION FOR LOWERING (POWER FAILURE):

When lowering through manual operation, should observe the condition of platform at any time because there are vehicles on the platform. If there is something abnormal, screw down oil loop valve immediately.

The process of manual operation:

- -firstly lift two safety pawls of platform and use that iron bar to fill up it.
- -switch off the power button (avoid abruptly incoming electricity). Open the back cover of control box to find the electromagnetic valve A for lowering.
- -loosen manual oil loop stud at the doll to be long electromagnetic valve core, then the platform begins lowering.
- -after the machine has been lowered, screw down manual oil loop stud timely, the process of manual lowering comes to the end.





## Chapter 6. Maintenance and care

Skilled personnel only is allowed to perform the operations.

- -all bearings and hinges on this machine must be lubricated once a week by using an oiler.
- -the safety gear, the upper and lower sliding blocks and other movable parts must be lubricated once o month.



-the hydraulic oil must be replaced one time each year. The oil level should always be kept at upper limit position.

The machine should be lower to the lowest position when replace hydraulic oil, then let the old oil out, and should be filter the hydraulic oil.

-Each team checks the agility and reliability of pneumatic safety equipment.



# Chapter 7. Failure and resolutions

Skill	ed personnel only is allowed to	perform the operations.
Failı	re Phenomena and Resolutions	
Failure Phenomena	slowly underno rmal loads.	Cause and Phenomena  (1) Connection of power supply wires is not correct.
	0	2 The AC contactor in the circuit of the motor does not pick up.
The motor does not run in lifting		1 The limit switch is not
operation.	The right and left	closed.  ① The motor turns reverse.
	not in the same height.	② Lifting with light load isnormal but no lifting withheavy load.
In lifting opera		
tion, the motor	N	③ The amount of hydraulicoil is not enough.
runs, but there is		④ The "operation stopvalve" is not closed.
nolifting movement	Table 3	① The safety pawl are not
	Table 3	released form the safety teeth.
		② The safety pawl is notlifted.
		③ The solenoid air valvedoes not work.
		4 The lowering solenoidvalve is energized but doesnot work.
When press "Lower" button,the machine isnot lowered		⑤ The "antiknock valve" isblocked.
		①The hydraulic oil has toohigh viscosity or
		frozen,deteriorated (in Winter).
		② The "antiknock valve" forpreventing oil pipe burst is blocked.
		① The air in the oil cylinderis not vent completely
		② Oil leakage on oil pipe orat its connections.
		③ The "oil make-up stopvalve" can not be closedtightly and almost make-upoil and adjust every day.
		①Lubrication is not enough.
		② The base or the machineis twisted.

The machine lowers extremely

Check and correct wire connection

If the motor operates when forcing the contactordown with an isolation rod. check the controlcircuit. If the voltage at two ends of contactorcoil is normal, replace the contactor.

Check the limit switch, wires and adjust orreplace the limit switch.

Change the phases of the power supply wires. The set safe pressure of the over-flow valve may

be increased by turning the set knob right wardslightly.

The spool of the lowering solenoid valve is stuckby dirt. Clean the spool.

Add hydraulic oil.

Screw

down the

"Operati

on stop

valve""Fi

rst lift a

little and

then

off,

lowering

The air pressure is not enough, the safety pawl isstuck or the air pipe is broken

adjustpressure,

If the solenoid air valve is energized, but doesnot open the air loop, check replace thesolenoid air valve.

Check the plug and coil of the lowering solenoidvalve and check the right turn tightness of its endcopper nut and so

Remove "antiknock valve" from the oilsupply hole at the bottom of the oil cylinder, andclean "antiknock valve".

with Replace hydraulic oil in accordance with theinstruction book.

Remove or close air supply pipe and thus lockthe safety pawl machine the without lifting ofthe safety pawl. Remove "antiknock valve"from the oil supply hole at the bottom of oilcylinder, and clean the "antiknock valve".


Refer to "VII. Oil Make-up 'Adjust' Operation".

Tighten oil pipe connections replace oil sealsand then make-up oil and adjust levelness.


Replace oil makeup stop valve, and thenmake-up oil and adjust.

Lubricate all hinges and motion parts (includingpiston rod) with machine oil

Adjust again the levelness of the machine, andfill or pad the base.



- 7. overflowing valve
- 8. descent valve
- 9. gear pump
- 10. throttling valve
- 11. pump motor



A: descent valve; B: manual descent knob; C: one-way valve; D: motor;

E: overflowing valve; F: Plug; G work stop valve; H, I. added stop valve;

Hose connection diagram

